

Flush Trim Laminate Router Bits



Used on kitchen counter tops and display case goods where the edge of a laminate must be trimmed flush to the edge or top of the material. Can be used on both plastic laminates and solid wood veneers. Use the 3 flute for even better finishes and on materials that tend to chip.

2 Flute - Bottom Bearing

| Part No. | Cutting Diameter | Cut Edge Length | Shank Diameter | Overall Length |
|----------|------------------|-----------------|----------------|----------------|
| RC719 | 3/8 | 1 | 1/4 | 2-5/8 |
| RC723 | 3/8 | 1/2 | 1/4 | 2-1/8 |
| RC726 | 1/2 | 1 | 1/4 | 2-11/16 |
| RC729 | 1/2 | 1/2 | 1/4 | 2-3/16 |
| RC735 | 1/2 | 1 | 1/2 | 3-1/4 |
| RC738 | 1/2 | 1/2 | 1/2 | 2-3/4 |
| RC741 | 1/2 | 1-1/2 | 1/2 | 3-5/8 |
| RC744 | 1/2 | 2 | 1/2 | 4-1/4 |

Use a B1 Bearing for Router Bits RC719 to RC723

3 Flute - Bottom Bearing

| Part No. | Cutting Diameter | Cut Edge Length | Shank Diameter | Overall Length |
|----------|------------------|-----------------|----------------|----------------|
| RC747 | 1/2 | 1 | 1/4 | 2-9/16 |
| RC749 | 1/2 | 1/2 | 1/4 | 2-1/8 |
| RC753 | 1/2 | 1 | 1/2 | 3-1/4 |
| RC756 | 1/2 | 1/2 | 1/2 | 2-3/4 |
| RC759 | 1/2 | 1-1/2 | 1/2 | 3-5/8 |
| RC760 | 1/2 | 2 | 1/2 | 4 |

All router bits use a B3 Bearing